webee®

GETTING STARTED WITH CLOSEE

This document is the property of Webee L.L.C.. The data contained here, in whole or in part, may not be duplicated, used or disclosed outside the recipient for any purpose. This restriction does not limit the recipient's right to use information contained in the data if it is obtained from another source without restriction.

INDEX

Section 1: Mounting your Closee

Instructions / Dimensions.....03

Section 2: Connecting to Smartee

Adding Closee to Zigbee Network.....04
Removing Closee from Zigbee Network.....04

Section 3: Specs

Electrical Specifications.....05
RF characteristics.....05

Section 4: Security Instructions

Security Guidelines.....06

© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

1 MOUNTING YOUR CLOSEE

Instructions



1- Adjust the wall bracket to the surface of your choice, then slide the sensor down on to the mounting fastener on the wall plate until the Snap Lock is secured.

Dimensions



© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

2 CONNECTING TO SMARTEE

Adding to Zigbee Network

To join the Closee to the Smartee, click on the “Add Device” function of your App and the Smartee will automatically connect your Closee to the network. For more detailed instructions check our Smartee User Manual.
If the Closee does not automatically join the network, press and hold the Closee button. The Closee will continuously blink as it attempts to join the hub.
Upon a successful joining of the Closee to the ZigBee network of your Smartee, the status LED will stop blinking.

If the after following these steps the Closee will not join the Smartee Zigbee network, do as follows:

•Make sure the Closee is powered up.
•Ensure the Closee is within RF range of a routing device.
• Make sure the network on your Smartee is open for joining. Keep in mind that once you clicked on Add Devices, the network will be open for 60 seconds.
•Check if the Closee hasn’t join another network (light will be static), see the next step to learn how to remove it from a network in order to add it to a new one.

Once the Closee is added to your Smartee, you will be able to start controlling it trough your Webee App.

Removing from Zigbee Network



If it becomes necessary to remove the Closee from a Zigbee network then you must factory default the Closee. To factory default the Closee:
A.Press and hold the press and hold the Connect button while inserting the battery.
D.Release the button when led is lit.
C.The Led will blink blue while attempting to connect to your Smartee.

© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

3 CLOSEE'S SPECS

Electrical specifications

Description	Min	Typ	Max	Unit
Rated	-	-	3	V
Battery	-	CR-2 (1x)	2-3	Years
Operating temperature	0°	-	40°	°C
Storage temperature	-20°	-	50°	°C
Operating Humidity	0	-	90%	RH (non-condensing)

Wireless RF Characteristics

Description	Min	Typ	Max	Unit
RF Channels	-	-	16	-
TX Strength	-	-	+20	dBm
Range	-	-	50+	ft.
Protocol		Zigbee HA 1.2		

© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

3 SAFETY INSTRUCTIONS

Safety Guidelines

-Clean only with a dry cloth.
-Do not install near any heat source such as radiators, stoves or other appliances (including amplifiers that produce heat.
-Only use attachments and accessories specified by the manufacturer.
-Follow all guidelines carefully, if you have any questions contact us at support@webeelife.com.

Warning: No user-serviciable parts inside. Refer all servicing to qualified service personnel.

Warning: Lift the top of your Closee to change it's battery. Closee use Cr2 Batteries. Risk of explosion if another type of battery is used.



© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

FCC Information

This device complies with Part 15B of the FCC rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference and
(2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.
This equipment generates, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful inerference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
· Reorient or relocate the receiving antenna.
· Increase the separation between the equipment and the receiver.
· Connect the equipment into an outlet different from that to which the receiver is connected.
· Consult the dealer or an experienced radio/TV technician for help.

Contains FCC ID:
W7Z-ZICM357SP2

© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC

V1.0 REV. January, 2015

© 2014 Webee LLC, All rights reserved. The Webee logo, Boss and Bees are trademarks or registered trademarks of Webee LLC